

# How to Wire Your ACE License Plate Relocate & 3<sup>rd</sup> Brake Light

1. Take the stock plug from your third brake light and feed it into the inside of the door.
2. Once it is inside the door we bring it back through the vent. We do this so that both wires are run together.
3. Cut the factory plug off of the third brake light.
4. Use 2 supplied butt connectors and connect the short wire on our relocate to the wires you just cut the plug off of.
5. The long wire you will run through the door and into the rear cargo area of your jeep.
6. Once the wire is run through the nylon strap you can find the stock wiring harness inside the jeep behind the passenger side taillight. Likely hidden by the carpet.
7. Use the 2 splice connectors to connect the red wire to white wire with purple stripe.
8. The black wire you can connect to the black wire in the wire harness.
9. After this turn on your running lights and make sure your license plate light is working and then hold the brake and make sure the third brake light is working.
10. After this just seal all connectors with electrical tape and you're finished.